


BALDASSARE II SUSPENSION



HOW TO INSTALL YOUR NEW LIGHT

Please verify that all components are included before installation.

If anything is missing, please contact us at:

customer@studioebur.com
www.studioebur.com


CAUTION

Risk of fire or electric shock. Turn off power at the circuit breaker before installation. Installation must be performed by a licensed electrician. Do not exceed specified wattage. Use only specified bulb type.

BALDASSARE II SUSPENSION


PART A

Fixture (lampshade + electrical assembly)
x1



PART B

Lag eye screws with toggle anchors
x3




PART C

S hooks
x9



PART D

Wrought iron suspension rod
x6



PART E


Wire connectors (UL-listed)
x3



BALDASSARE II SUSPENSION


STEP 01

Switch off power at the main electrical panel before installation. Ensure the electrical connection point is properly installed and secured.




STEP 02

Position the electrical outlet within the 60 cm (23.6 in) projection circle. Mark the three lag eye screws on the circle, forming an equilateral triangle with 49 cm (19.3 in) between each point. Position one eye screw close to the electrical outlet.




STEP 03

Secure the lag eye screws at the previously marked locations.




STEP 04

Attach the S-hooks and suspension rods, then hang the lampshade using the dedicated rings.




STEP 05

Guide the electrical cable along the suspension rod located closest to the electrical outlet.



STEP 06


Connect black to black (line/hot), white to neutral, and green or bare to ground using UL-listed wire connectors. Ensure connections are secure and insulated.



BALDASSARE II SUSPENSION

STEP 07

Hide the electrical connector inside the ceiling, then close and finish the ceiling to conceal the opening.



STEP 08

Insert one E26 LED bulb (not included). Restore power at the circuit breaker and test the fixture.



BALDASSARE II SUSPENSION

HOW TO CLEAN YOUR LAMP

Turn off power at the switch or circuit breaker before cleaning. Clean with a soft, dry cloth only. Do not use water or harsh cleaning products.

FABRIC LAMPSHADE

To preserve the quality of the fabric, clean only with a soft, dry cloth. Do not use water, moisture, or harsh cleaning products.

GOOD TO KNOW

For dimming, use a dimmable bulb with a compatible dimmer.

SOLD SEPARATELY

Light bulb not included. Use one E26 LED bulb, 10W max, 2700K recommended.

IMPORTANT NOTICE

This product is designed to meet applicable U.S. safety standards. Installation must be performed by a licensed electrician.

END OF LIFE OF THE PRODUCT



This product must not be disposed of with household waste. Please dispose of it in accordance with local regulations and recycling requirements.