


## GIZA II SUSPENSION



### HOW TO INSTALL YOUR NEW LIGHT

Please verify that all components are included before installation.

*If anything is missing, please contact us at:*

customer@studioebur.com  
www.studioebur.com


### CAUTION

Risk of fire or electric shock. Turn off power at the circuit breaker before installation. Installation must be performed by a licensed electrician. Do not exceed specified wattage. Use only specified bulb type.

## GIZA II SUSPENSION


### PART A

Fixture (lampshade + electrical assembly)  
x1



### PART B

Lag eye screws with toggle anchors  
x4




### PART C

S hooks  
x8



### PART D

Wrought iron suspension rod  
x4



### PART E


Wire connectors (UL-listed)  
x3



## GIZA II SUSPENSION


### STEP 01

Switch off power at the main electrical panel before installation. Ensure the electrical connection point is properly installed and secured.




### STEP 02

Mark the four corner points of the lampshade on the ceiling.




### STEP 03

Secure the lag eye screws at the previously marked locations (Part B).




### STEP 04

Attach the S-hooks and suspension rods, then hang the lampshade using the dedicated rings (Part C, Part D, Part A)



### STEP 05

Guide the electrical cable along the suspension rod located closest to the electrical outlet.



### STEP 06


Connect black to black (line/hot), white to neutral, and green or bare to ground using UL-listed wire connectors. Ensure connections are secure and insulated.



## GIZA II SUSPENSION


### STEP 07

Hide the electrical connector inside the ceiling, then close and finish the ceiling to conceal the opening.



### STEP 08

Insert four E26 LED bulbs (not included). Restore power at the circuit breaker and test the fixture.



## GIZA II SUSPENSION

### HOW TO CLEAN YOUR LAMP

Turn off power at the switch or circuit breaker before cleaning. Clean with a soft, dry cloth only. Do not use water or harsh cleaning products.

### FABRIC LAMPSHADE

To preserve the quality of the fabric, clean only with a soft, dry cloth. Do not use water, moisture, or harsh cleaning products.

### GOOD TO KNOW

For dimming, use a dimmable bulb with a compatible dimmer.

### SOLD SEPARATELY

Light bulb not included. Use one E26 LED bulb, 10W max, 2700K recommended.

### IMPORTANT NOTICE

This product is designed to meet applicable U.S. safety standards. Installation must be performed by a licensed electrician.

### END OF LIFE OF THE PRODUCT



This product must not be disposed of with household waste. Please dispose of it in accordance with local regulations and recycling requirements.