


CHIMERA WALL LAMP



HOW TO INSTALL YOUR NEW LIGHT

Please verify that all components are included before installation.

If anything is missing, please contact us at:

customer@studioebur.com
www.studioebur.com

CAUTION


Risk of fire or electric shock. Turn off power at the circuit breaker before installation. Installation must be performed by a licensed electrician. Do not exceed specified wattage. Use only specified bulb type.

CHIMERA WALL LAMP

PART A

Mounting assembly (mounting plate + mounting screws)


x1



PART B

Fixture (canopy + electrical assembly) + Canopy mounting screws


x1



PART C

Wire connector

x1



PART D

L hooks


x2



PART E

Plaster shell


x1



PART F

Fabric shade


x1



CHIMERA WALL LAMP


STEP 01

Switch off power at the main electrical panel before installation. Ensure the electrical connection point is properly installed and secured.




STEP 02

Attach the mounting plate to the wall using the provided screws.




STEP 03

Connect the wires as follows. Brown or black to L (live), blue to N (neutral), green/yellow to earth (ground). Ensure all connections are secure and properly insulated.




STEP 04

Attach the fixture to the mounting plate and secure it with the provided hardware (Part B).




STEP 05

Mark the fixing points according to the measurements, then install the two L hooks (Part D) into the wall. Install the two bulbs into the sockets.



STEP 06


Insert the fabric shade (Part F) into the plaster shell (Part E).



CHIMERA WALL LAMP


STEP 07

Attach the assembled plaster shell and fabric shade to the two L-hooks.



STEP 08

Restore power at the circuit breaker and test the fixture.



CHIMERA WALL LAMP

HOW TO CLEAN YOUR LAMP

Turn off power before cleaning. Clean with a soft, dry cloth only. Do not use water or harsh cleaning products.

GOOD TO KNOW

For dimming, use a dimmable bulb with a compatible dimmer.

SOLD SEPARATELY

Light bulb sold separately.

EBUR recommends the E27 LED light bulb (max. 10W) with a warm color temperature of up to 2700 K.

IMPORTANT NOTICE

This product complies with applicable European safety standards. Installation should be carried out by a qualified electrician.

END OF LIFE OF THE PRODUCT



This product must not be disposed of with household waste. Please dispose of it in accordance with local regulations and recycling requirements.